



LEDs attached to flight computers will flash if and only if both Logic and Pyro battery power is supplied to the flight computer.

Molex .062 connectors used to separate the circuit on mechanical boundaries are indicated by gray ellipses.

Title Dragonfire2 Chassis Wiring		
Author B. Feretich		
File ckets\EndeavourMods\EndeavourAvionicsV2.dsn	Document	
Revision 2.0	Date 4/11/08	Sheets 1 of 1